

Custom properties

Version 1.1

See also: <https://support.tekla.com/article/finland-environment-custom-properties>

Version history:

Version	Author	Date	Description
1.0	Teemu Anttila	20.5.2016	The first version of the document
1.1	Teemu Anttila	17.5.2023	Added CUSTOM.BUILDING, CUSTOM.ELEMENT_WEIGHT.REINFORCED, CUSTOM.ELEMENT_POS.BY_DRAWING, CUSTOM.NUMBER, CUSTOM.SLAB_CAST_UNIT_POS.BY_DRAWING that were implemented a couple of years ago Added chapters for: CustomEmbedProperties.dll CustomFilterGroupProperties.dll CustomObjectTypeProperties.dll

Contents

Preface	9
1 BeamCustomProperties.dll	10
1.1 CUSTOM.WEB_THICKNESS	10
Modeling requirements	10
Usage	10
Row and value type	10
Supported profiles	10
1.2 CUSTOM.RIB_WIDTH	10
Modeling requirements	10
Usage	10
Row and value type	10
Supported profiles	11
1.3 CUSTOM.BOTTOM_FLANGE_THICKNESS_1	11
Modeling requirements	11
Usage	11
Row and value type	11
Supported profiles	11
1.4 CUSTOM.BOTTOM_FLANGE_THICKNESS_2	11
Modeling requirements	11
Usage	11
Row and value type	12
Supported profiles	12
2 ElementCustomProperties.dll	13
2.1 CUSTOM.ELEMENT_POS	13
Modeling requirements	13
Usage	13
Row and value type	13
Supported cast units	13
2.2 CUSTOM.ELEMENT_POS.BY_DRAWING	13
2.3 CUSTOM.NUMBER	13
2.4 CUSTOM.ELEMENT_MARK	13
Modeling requirements	13
Usage	14
Row and value type	14
Supported cast units	14
2.5 CUSTOM.SIMILAR_ELEMENT_POS_LIST	14
Requirements	14
Usage	14
Return value	14
Supported cast units	15

2.6	CUSTOM.ACN	15
	Requirements	15
	Usage	15
	Return value	15
2.7	CUSTOM.CAST_UNIT_NAME	15
	Requirements	15
	Usage	15
	Return value	15
3	LocationCustomProperties.dll	16
3.1	CUSTOM.FLOOR	16
	Requirements	16
	Usage	16
	Return value	16
	Supported cast units	16
3.2	CUSTOM.SECTION	16
	Requirements	16
	Usage	16
	Return value	17
	Supported cast units	17
3.3	CUSTOM.BUILDING	17
	Requirements	17
	Usage	17
	Return value	17
	Supported cast units	17
4	SlabCustomProperties.dll	18
4.1	CUSTOM.SLAB_INSULATION_MATERIAL	18
	Modeling requirements	18
	Usage	18
	Row and value type	18
	Supported cast units	18
4.2	CUSTOM.SLAB_INSULATION_THICKNESS	18
	Modeling requirements	18
	Usage	18
	Row and value type	19
	Supported cast units	19
4.3	CUSTOM.SLAB_CAST_UNIT_POS	19
	Modeling requirements	19
	Usage	19
	Row and value type	19
	Supported cast units	19
4.4	CUSTOM.SLAB_CAST_UNIT_POS.BY_DRAWING	19
4.5	CUSTOM.SLAB_CAST_UNIT_MARK	20
	Modeling requirements	20
	Usage	20
	Row and value type	20

4.6	CUSTOM.IS_DETAILED_SLAB	20
	Modeling requirements	20
	Usage	20
	Row and value type	20
5	CustomWallProperties.dll	22
5.1	CUSTOM.INNER_PANEL_MATERIAL	22
	Modeling requirements	22
	Usage	22
	Row and value type	22
	Supported cast units	22
5.2	CUSTOM.INNER_PANEL_THICKNESS	22
	Modeling requirements	22
	Usage	23
	Row and value type	23
	Supported cast units	23
5.3	CUSTOM.INNER_PANEL_VOLUME	23
	Modeling requirements	23
	Usage	23
	Row and value type	23
	Supported cast units	24
5.4	CUSTOM.INSULATION_MATERIAL	24
	Modeling requirements	24
	Usage	24
	Row and value type	24
	Supported cast units	24
5.5	CUSTOM.INSULATION_THICKNESS	24
	Modeling requirements	24
	Usage	25
	Row and value type	25
	Supported cast units	25
5.6	CUSTOM.OUTER_PANEL_MATERIAL	25
	Modeling requirements	25
	Usage	26
	Row and value type	26
	Supported cast units	26
5.7	CUSTOM.OUTER_PANEL_THICKNESS	26
	Modeling requirements	26
	Usage	26
	Row and value type	26
	Supported cast units	26
5.8	CUSTOM.OUTER_PANEL_VOLUME	27
	Modeling requirements	27
	Usage	27
	Row and value type	27
	Supported cast units	27

5.9	CUSTOM.SURFACE_TREATMENT_NAME_1	27
5.10	CUSTOM.SURFACE_TREATMENT_NAME_2	27
5.11	CUSTOM.SURFACE_TREATMENT_NAME_3	27
	Modeling requirements	27
	Usage	27
	Row and value type	28
	Supported cast units	28
5.12	CUSTOM.SURFACE_TREATMENT_AREA_1	28
5.13	CUSTOM.SURFACE_TREATMENT_AREA_2	28
5.14	CUSTOM.SURFACE_TREATMENT_AREA_3	28
	Modeling requirements	28
	Usage	28
	Row and value type	28
	Supported cast units	28
6	ElementWeight.dll	29
6.1	CUSTOM.ELEMENT_WEIGHT	29
6.2	CUSTOM.ELEMENT_WEIGHT.REINFORCED	29
7	CustomEmbedProperties.dll	29
7.1	CUSTOM.EMBED.IS_EMBED	29
	Modeling requirements	29
	Usage	29
	Row and value type	29
7.2	CUSTOM.EMBED.BELONGS_TO	29
	Modeling requirements	29
	Usage	30
	Row and value type	30
	Supported cast units	30
7.3	CUSTOM.EMBED.TYPE	30
	Modeling requirements	30
	Usage	30
	Row and value type	30
	Supported cast units	30
7.4	CUSTOM.EMBED.BUILDING	30
	Modeling requirements	30
	Usage	30
	Row and value type	31
	Supported cast units	31
7.5	CUSTOM.EMBED.SECTION	31
	Modeling requirements	31
	Usage	31
	Row and value type	31
	Supported cast units	31
7.6	CUSTOM.EMBED.FLOOR	31
	Modeling requirements	31
	Usage	31

	Row and value type	32
	Supported cast units	32
7.7	CUSTOM.EMBED.QUANTITY	32
	Modeling requirements	32
	Usage	32
	Row and value type	32
	Supported cast units	32
7.8	CUSTOM.EMBED.UNIT	32
	Modeling requirements	32
	Usage	32
	Row and value type	33
	Supported cast units	33
7.9	CUSTOM.EMBED.ORDER_INFO	33
	Modeling requirements	33
	Usage	33
	Row and value type	33
	Supported cast units	33
7.10	CUSTOM.EMBED.PRODUCT_CODE	33
	Modeling requirements	33
	Usage	33
	Row and value type	34
	Supported cast units	34
8	CustomFilterGroupProperties.dll	34
8.1	CUSTOM.FILTER.CLASS_ATTR.GROUP	34
	Modeling requirements	34
	Usage	34
	Row and value type	34
9	CustomObjectTypeProperties.dll	34
9.1	CUSTOM.ASSEMBLY_TYPE	35
	Modeling requirements	35
	Usage	35
	Row and value type	35
	Supported cast units	35
9.2	CUSTOM.OBJECT_TYPE	35
	Modeling requirements	35
	Usage	35
	Row and value type	35
	Supported cast units	36
9.3	CUSTOM.MATERIAL_TYPE	36
	Modeling requirements	36
	Usage	36
	Row and value type	36
	Supported cast units	37
9.4	CUSTOM.CROSS_SECTION_TYPE	37
	Modeling requirements	37

	Usage	37
	Row and value type	37
	Supported cast units	38
9.5	CUSTOM.MANUFACTURED_AT	38
	Modeling requirements	38
	Usage	38
	Row and value type	39
	Supported cast units	39
9.6	CUSTOM.IFC_GUID	39
	Modeling requirements	39
	Usage	39
	Row and value type	39
	Supported cast units	39

Preface

This document is related to BEC project's quantity lists created using Tekla Structures Organizer tool.

Certain information cannot be directly asked from Tekla Structures, but it is possible to program Custom property plug-ins (compiled into dll files) that can be added to Tekla Structures folder structure.

This document contains descriptions of the implemented Custom properties and their pre conditions and limitations.

The custom property dll files were published like presented in the document for the first time in version Tekla Structures 21.0 Service Release 7.

1 BeamCustomProperties.dll

1.1 CUSTOM.WEB_THICKNESS

Modeling requirements

Cast unit prefix must begin with

- K (normally reinforced concrete beam)
- JK (prestressed, pretensioned concrete beam)

Usage

- Organizer quantity lists

Row and value type

Works for PART and CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: Web thickness
- Text: empty string

Supported profiles

- RCL, RCDL, RCXX, RCDX, RCX
- JKMP (Parma middle beam), JKSIDE (Parma edge beam)
- PRMB (Luja middle beam), LBL (Luja edge beam)
- BMK (Betonimestarit middle beam), BMR (Betonimestarit edge beam)

1.2 CUSTOM.RIB_WIDTH

Modeling requirements

Cast unit prefix must begin with

- TT (Traditional TT-slab)
- TEK (Parma's light weight TT-slab)
- SUPERTT (Luja's light weight TT-slab)
- RIB (Shallow rib slab)

Usage

- Organizer quantity lists

Row and value type

Works for PART and CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: Rib width
- Text: empty string

Supported profiles

See modelling requirements

1.3 CUSTOM.BOTTOM_FLANGE_THICKNESS_1

Modeling requirements

Cast unit prefix must begin with

- K (normally reinforced concrete beam)
- JK (prestressed, pretensioned concrete beam)

Usage

- Organizer quantity lists

Row and value type

Works for PART and CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: Flange thickness 1
- Text: empty string

Supported profiles

- RCL, RCDL, RCXX, RCDX, RCX
- JKMP (Parma middle beam), JKSIDE (Parma edge beam)
- PRMB (Luja middle beam), LBL (Luja edge beam)
- BMK (Betonimestarit middle beam), BMR (Betonimestarit edge beam)

1.4 CUSTOM.BOTTOM_FLANGE_THICKNESS_2

Modeling requirements

Cast unit prefix must begin with

- K (normally reinforced concrete beam)
- JK (prestressed, pretensioned concrete beam)

Usage

- Organizer quantity lists

Row and value type

Works for PART and CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: Flange thickness 2
- Text: empty string

Supported profiles

- RCDL, RCXX, RCDX, RCX
- JKMP (Parma middle beam)
- PRMB (Luja middle beam)
- BMK (Betonimestarit middle beam)

2 ElementCustomProperties.dll

2.1 CUSTOM.ELEMENT_POS

Modeling requirements

No special requirements

Usage

- Organizer quantity lists
- Model view part label (shows value only for main part)

Row and value type

Works for PART and CAST_UNIT template rows

- PART rows: return value only for cast unit main part

Return value:

- Number: 0
- Number with decimals: 0.0
- Text:
 - o Value is formed by Finland environment's project UDA
P_ELEMENT_POS_TYPE
 - [01 CAST_UNIT_POS |
02 CAST_UNIT_PREFIX + ACN]
 - o For Hollow core (prefix starts with O) and plank slabs (prefix starts with KL) returns CUSTOM.SLAB_CAST_UNIT_POS value

Supported cast units

- Only precast (not cast-in-place)

2.2 CUSTOM.ELEMENT_POS.BY_DRAWING

See CUSTOM.ELEMENT_POS. This custom property is designed to be used in the XS_DRAWING_PLOT_FILE_NAME_C.

2.3 CUSTOM.NUMBER

This custom property is designed to be used in the XS_DRAWING_PLOT_FILE_NAME_C to include the number of elements to be manufactured by a drawing into the file name.

2.4 CUSTOM.ELEMENT_MARK

Modeling requirements

No special requirements

Usage

- Organizer quantity lists
- GA drawing part mark

Row and value type

Works for PART and CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: 0.0
- Text:
 - o Value is formed by Finland environment's project UDA
P_ELEMENT_POS_TYPE
 - [01 CAST_UNIT_POS |
02 CAST_UNIT_PREFIX + ACN]
 - o For Hollow core (prefix starts with O) and plank slabs (prefix starts with KL) returns CUSTOM.SLAB_CAST_UNIT_MARK value

Supported cast units

- Only precast (not cast-in-place)

2.5 CUSTOM.SIMILAR_ELEMENT_POS_LIST

Requirements

Useful only if Finland environment's project UDA
P_ELEMENT_POS_TYPE has value "02 CAST_UNIT_PREFIX + ACN".
This is used for example by precast element manufacturer Lujabetoni.

Usage

- For naming plot files (e.g. pdf files)
- Can be used as part of environment variable
XS_DRAWING_PLOT_FILE_NAME_C value.
For example:
XS_DRAWING_PLOT_FILE_NAME_C=%TPL:CUSTOM.SIMILAR_ELEMENT_POS_LIST%%_1_1%%DRAWING_REVISION?#%%REVISION_MARK%

Return value

Return value is of text type:

- o Algorithm searches all cast units that are represented by the same drawing (having same CAST_UNIT_POS). Then it is concatenating the CUSTOM.ELEMENT_POS values of all of those cast units.
- o Example:
Drawing represents ELEMENT_POS values P1, P2, P3, P4, P5, P8

and P11.

The value of CUSTOM.SIMILAR_ELEMENT_POS_LIST is then “P1;;P5;P8;P11”. Note that “P1;;P5” represents values P1, P2, P3, P4 and P5. This syntax has been defined by Lujabetoni to name pdf files for their manufacturing system.

Supported cast units

- Only precast (not cast-in-place)

2.6 CUSTOM.ACN

Requirements

ACN value exist on cast unit

Usage

- Add CUSTOM.ACN on Model view’s Part label. The value is drawn into view only for cast unit main part, which makes the view easier to read.

Return value

If not set, returns empty string for model view.
Otherwise the integer value is converted into string.

2.7 CUSTOM.CAST_UNIT_NAME

Requirements

No requirements.

Usage

- Add CUSTOM.CAST_UNIT_NAME on Model view’s Part label. The value is drawn into view only for cast unit main part, which makes the view easier to read.

Return value

Shows cast unit’s name or main parts name if cast unit name has no value.

3 LocationCustomProperties.dll

3.1 CUSTOM.FLOOR

Requirements

The user has produced floor information to one of these locations:

- By using Organizer tool (which saves the floor information that can be asked by LOCATION_BREAKDOWN_STRUCTURE.LBS_FLOOR
- User defined attribute BLD_FLOOR (Finland Environment UDA)
- User defined attribute IFC_BUILDING_STOREY

Usage

- For getting floor information of precast concrete elements into lists created by Organizer's Object browser.
- Finland Environments project's user defined attribute P_LOCATION_SOURCE defines where the floor value is read
[01 IFC building and storey |
02 Organizer section and floor |
03 Finland environment section and floor]

Return value

Return value is of text type.

Value is asked from assembly.

If asked from a part, the return value is the value asked from part's assembly.

Supported cast units

- Both precast and cast-in-place assemblies

3.2 CUSTOM.SECTION

Requirements

The user has produced section information to one of these locations:

- By using Organizer tool (which saves the floor information that can be asked by LOCATION_BREAKDOWN_STRUCTURE.LBS_SECTION
- User defined attribute BLD_SECTION (Finland Environment UDA)
- User defined attribute IFC_BUILDING

Usage

- For getting section information of precast concrete elements into lists created by Organizer's Object browser.
- Finland Environments project's user defined attribute P_LOCATION_SOURCE defines where the floor value is read
[01 IFC building and storey |

02 Organizer section and floor |
03 Finland environment section and floor]

Return value

Return value is of text type.

Value is asked from assembly.

If asked from a part, the return value is the value asked from part's assembly.

Supported cast units

- Both precast and cast-in-place assemblies

3.3 CUSTOM.BUILDING

Requirements

The user has produced building information to one of these locations:

- By using Organizer tool (which saves the floor information that can be asked by LOCATION_BREAKDOWN_STRUCTURE.LBS_BUILDING
- User defined attribute IFC_BUILDING

Usage

- For getting section information of precast concrete elements into lists created by Organizer's Object browser.
- Finland Environments project's user defined attribute P_LOCATION_SOURCE defines where the floor value is read
[01 IFC building and storey |
02 Organizer section and floor |
03 Finland environment section and floor]

Return value

Return value is of text type.

Value is asked from assembly.

If asked from a part, the return value is the value asked from part's assembly.

Supported cast units

- Both precast and cast-in-place assemblies

4 SlabCustomProperties.dll

4.1 CUSTOM.SLAB_INSULATION_MATERIAL

Modeling requirements

Only works for such cast units which prefix starts with

- O (hollow core slabs)
- KL (plank slabs)
- EL (insulated massive slab)
- L (massive slab)

Usage

- Organizer quantity lists

Row and value type

Works for PART and CAST_UNIT template rows

- PART rows: return value only for cast unit main part

Return value:

- Number: 0
- Number with decimals: 0.0
- Text:
 - o Searches cast unit parts that have MATERIAL_TYPE = MISCELLANEOUS
 - o Return the MATERIAL value of the part that is biggest by volume

Supported cast units

- See Modeling requirements

4.2 CUSTOM.SLAB_INSULATION_THICKNESS

Modeling requirements

Only works for such cast units which prefix starts with

- O (hollow core slabs)
- KL (plank slabs)
- EL (insulated massive slab)
- L (massive slab)

Usage

- Organizer quantity lists

Row and value type

Works for PART and CAST_UNIT template rows

- PART rows: return value only for cast unit main part

Return value:

- Number: converted double value into integer
- Number with decimals:
 - o Searches cast unit parts that have MATERIAL_TYPE = MISCELLANEOUS
 - o Returns the thickness of the part that is biggest by volume
- Text: string where double value is formatted into number with zero decimals

Supported cast units

- See Modeling requirements

4.3 CUSTOM.SLAB_CAST_UNIT_POS

Modeling requirements

Only works for such cast units which prefix starts with

- O (hollow core slabs)
- KL (plank slabs)

Usage

- Organizer quantity lists
- Model view part label (shows value only for main part)

Row and value type

Works for PART and CAST_UNIT template rows

- PART rows: return value only for cast unit main part

Return value:

- Number: 0
- Number with decimals: 0.0
- Text:
 - o PROFILE + “-“ + CAST_UNIT_SERIAL_NUMBER
 - o if the cast unit has not been numbered
PROFILE + “-(?)”

Supported cast units

- Only precast (not cast-in-place)

4.4 CUSTOM.SLAB_CAST_UNIT_POS.BY_DRAWING

Designed to be used in XS_DRAWING_PLOT_FILE_NAME_C

4.5 CUSTOM.SLAB_CAST_UNIT_MARK

Modeling requirements

Only works for such cast units which prefix starts with

- O (hollow core slabs)
- KL (plank slabs)

Usage

- GA-drawing part marks

Row and value type

Works for PART and CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: 0.0
- Text:
 - If strand info has been given in user defined attribute STRAND_INFO PROFILE + “- “ + STRAND_INFO + “ -“ + CAST_UNIT_SERIAL_NUMBER
 - Otherwise PROFILE + “- -“ + CAST_UNIT_SERIAL_NUMBER
 - If the cast unit has not been numbered, CAST_UNIT_SERIAL_NUMBER is replaced with “(?)”

4.6 CUSTOM.IS_DETAILED_SLAB

Modeling requirements

Only works for such cast units which prefix starts with

- O (hollow core slabs)
- KL (plank slabs)

Usage

- Template editor reports
- The idea is to “raise a flag” if the factory production line must do something else that cut the slab with perpendicular sawing

Row and value type

Works for PART and CAST_UNIT template rows, only gives value for assembly or main part.

Return value:

- Number: 0
- Number with decimals: 0.0
- Text: {"TRUE" | "FALSE"}

Checks:

- Is the assembly a cast unit? AND
- Does main part contain rebars? OR
- Does main part contain part cuts? OR
- Does main part contain non-perpendicular plane cuts or fittings? OR
- Does main part contain steel embeds? OR
- Does cast unit contain more than one concrete part?

5 CustomWallProperties.dll

5.1 CUSTOM.INNER_PANEL_MATERIAL

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- SK (load bearing inner shell)
- RK (not load bearing inner shell)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: 0.0
- Text: MATERIAL of the biggest concrete part which name contains substring "INNER" or "SISÄ"

Supported cast units

- See Modeling requirements

5.2 CUSTOM.INNER_PANEL_THICKNESS

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- SK (load bearing inner shell)
- RK (not load bearing inner shell)
- S (load bearing sandwich)
- R (not load bearing sandwich)

- NK (load bearing strip element)
- N (not load bearing strip element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: double value rounded to integer
- Number with decimals: thickness of the inner panel
Value asked from concrete part biggest by volume and recognized as inner panel by name
- Text: double value formatted to text with zero decimals

Supported cast units

- See Modeling requirements

5.3 CUSTOM.INNER_PANEL_VOLUME

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- SK (load bearing inner shell)
- RK (not load bearing inner shell)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: thickness of the inner panel
Sum of concrete part volumes recognized as inner panel by name
- Text: empty string

Supported cast units

- See Modeling requirements

5.4 CUSTOM.INSULATION_MATERIAL

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- SK (load bearing inner shell)
- RK (not load bearing inner shell)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: 0.0
- Text: MATERIAL of the biggest miscellaneous material type part which name contains substring "INSULATION" or "ERISTE" or class is 104

Supported cast units

- See Modeling requirements

5.5 CUSTOM.INSULATION_THICKNESS

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- SK (load bearing inner shell)
- RK (not load bearing inner shell)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: double value rounded to integer
- Number with decimals: thickness of the insulation part
Value asked from miscellaneous material type part biggest by volume and recognized as insulation by name or class
- Text: double value formatted to text with zero decimals

Supported cast units

- See Modeling requirements

5.6 CUSTOM.OUTER_PANEL_MATERIAL

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- KE (outer shell element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: 0.0
- Text: MATERIAL of the biggest concrete part which name contains substring "OUTER" or "ULKO"

Supported cast units

- See Modeling requirements

5.7 CUSTOM.OUTER_PANEL_THICKNESS

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- KE (outer shell element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: double value rounded to integer
- Number with decimals: thickness of the inner panel
Value asked from concrete part biggest by volume and recognized as outer panel by name
- Text: double value formatted to text with zero decimals

Supported cast units

- See Modeling requirements

5.8 CUSTOM.OUTER_PANEL_VOLUME

Modeling requirements

Only works for such cast units which prefix starts with

- SKR (load bearing plastered sandwich)
- RKR (not load bearing plastered sandwich)
- S (load bearing sandwich)
- R (not load bearing sandwich)
- NK (load bearing strip element)
- N (not load bearing strip element)
- KE (outer shell element)
- AS (load bearing socle element)
- AN (not load bearing socle element)
- AR (ground pressure socle element)

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: thickness of the inner panel
Sum of concrete part volumes recognized as outer panel by name
- Text: empty string

Supported cast units

- See Modeling requirements

5.9 CUSTOM.SURFACE_TREATMENT_NAME_1

5.10 CUSTOM.SURFACE_TREATMENT_NAME_2

5.11 CUSTOM.SURFACE_TREATMENT_NAME_3

Modeling requirements

Surface treatments have been modelled to cast unit as surface treatment objects

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: 0.0
- Text: NAME or surface treatment which area is biggest / second biggest / third biggest

Supported cast units

- See Modeling requirements

5.12 CUSTOM.SURFACE_TREATMENT_AREA_1

5.13 CUSTOM.SURFACE_TREATMENT_AREA_2

5.14 CUSTOM.SURFACE_TREATMENT_AREA_3

Modeling requirements

Surface treatments have been modelled to cast unit as surface treatment objects

Usage

- Organizer quantity lists

Row and value type

Works for CAST_UNIT template rows

Return value:

- Number: 0
- Number with decimals: sums areas of surface treatment objects. Sorted by area and reported by biggest / second biggest / third biggest area.
- Text: empty string

Supported cast units

- See Modeling requirements

6 ElementWeight.dll

6.1 CUSTOM.ELEMENT_WEIGHT

Loops through cast unit parts and sums their weight.

Ignores subassemblies which are made from steel as their weight is already included in a slightly higher density value of concrete parts.

6.2 CUSTOM.ELEMENT_WEIGHT.REINFORCED

Loops through cast unit parts and sums their weight. Calculates volume of reinforcing bars and reduces that from concrete volume. Uses 2450 kg/m³ for concrete and 7850 kg/m³ for steel and reinforcement.

This is valid only for such elements that are fully reinforced.

7 CustomEmbedProperties.dll

7.1 CUSTOM.EMBED.IS_EMBED

Modeling requirements

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Text: TRUE | FALSE, based on the class value

7.2 CUSTOM.EMBED.BELONGS_TO

Modeling requirements

The embed has been added to a cast unit as subassembly

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Text: element or cast-in-place cast unit position number

Supported cast units

- See Modeling requirements

7.3 CUSTOM.EMBED.TYPE

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Text: Loose (Irrallinen), Precast element (Elementti), Cast-in-place concrete (Paikallavalu)

Supported cast units

- All

7.4 CUSTOM.EMBED.BUILDING

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Text: Building of the cast unit where the embed belongs to or Building of the embed itself, if it is a hierarchy level 0 embed.

Supported cast units

- All

7.5 CUSTOM.EMBED.SECTION

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Text: Section of the cast unit where the embed belongs to or Building of the embed itself, if it is a hierarchy level 0 embed.

Supported cast units

- All

7.6 CUSTOM.EMBED.FLOOR

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Text: Floor (building storey) of the cast unit where the embed belongs to or Building of the embed itself, if it is a hierarchy level 0 embed.

Supported cast units

- All

7.7 CUSTOM.EMBED.QUANTITY

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- Number with decimals: Depending on the class the quantity can be count, length or area

Supported cast units

- All

7.8 CUSTOM.EMBED.UNIT

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- String: Pcs (kpl), m, m², depending of the class of the embed

Supported cast units

- All

7.9 CUSTOM.EMBED.ORDER_INFO

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- String: Values of ASSEMBLY_NAME and user-defined attribute PRODUCT_DESCR concatenated

Supported cast units

- All

7.10 CUSTOM.EMBED.PRODUCT_CODE

Modeling requirements

-

Usage

Organizer quantity lists, templates & reports

Row and value type

Works for ASSEMBLY, PART and REBAR template rows. Embeds should be modelled as subassemblies, but it is possible to have e.g. wooden parts that belong directly to the cast unit. A single reinforcing bar or reinforcing bar group can also be an embed.

Return value:

- String: Value of the user-defined attribute PRODUCT_CODE of the embed

Supported cast units

- All

8 CustomFilterGroupProperties.dll

8.1 CUSTOM.FILTER.CLASS_ATTR.GROUP

The additional property set definitions of **FI_Property_sets** use filtering for the property definitions. This way for example it is possible to define a property set for piles. The filtering functionality is on very elementary level and it is not possible to use AND and OR operators reasonably. For defining group that contain for example many class attribute values logically combined with an OR operator, custom property reads the CUSTOM.FILTER.CLASS_ATTR.GROUP.ini file from the model folder. In the .ini file there are rows like this

```
430 ; PILE
431 ; PILE
432 ; PILE
```

that consist of the class values separated with the group name. Then it is possible to use the group name (in this case PILE) in the filtering conditions.

Modeling requirements

Class of the assembly is set

Usage

IFC Export

Row and value type

Return value:

- String: The group name searched using the class numerical value

9 CustomObjectTypeProperties.dll

9.1 CUSTOM.ASSEMBLY_TYPE

Modeling requirements

-

Usage

Primarily for IFC export, classifying of structures

Row and value type

ASSEMBLY and CAST_UNIT

Return value:

- String: CONCRETE ELEMENT (BETONIELEMENTTI) |
CAST-IN-PLACE CONCRETE (PAIKALLAVALU) |
STEEL ASSEMBLY (TERÄSKOKOONPANO) |
TIMBER ASSEMBLY (PUUKOKOONPANO) |
REINFORCEMENT ASSEMBLY (RAUDOITEKOKOONPANO) |
OTHER ASSEMBLY (MUU KOKOONPANO)
based on Tekla Structures MATERIAL_TYPE

Supported cast units

- All

It is also possible to append this custom property by .IN_ENGLISH, .IN_FINNISH and .IN_SWEDISH

9.2 CUSTOM.OBJECT_TYPE

Modeling requirements

The value is based on CLASS_ATTR. The numerical class values are paired with structure Generic name string values in a text file CustomObjectType.ini.

The idea is that every engineering office would use the same Generic names for structures but could use their own class values to achieve that.

Usage

Primarily for IFC export, classifying of structures

Row and value type

ASSEMBLY and CAST_UNIT

Return value (examples of Generic names):

- String:
GROUND WATER LEVEL (POHJAVEDEN KORKEUS)

GROUND SURFACE (MAANPINTA)
 PILE PENETRATION SURFACE (PAALUJEN TUNKEUMATASO)
 STEEL PILE (TERÄKSINEN LYÖNTIPAALU)
 DRILL PILE (PORAPAALU)
 UNDERDRAIN PILE (SALAOJAPUTKI)
 STRIP FOOTING ON PILES (JATKUVA PAALUANTURA)
 LEVELING CONCRETE (KALLISTUSVALU)
 ARS WALL (VSS-SEINÄ)
 RIB SLAB (RIPALAATTA)
 THERMAL INSULATOR (LÄMMÖNERISTE)
 AIR CHANNEL ELEMENT (HORMIELEMENTTI)

Supported cast units

- All

It is also possible to append this custom property by .IN_ENGLISH, .IN_FINNISH and .IN_SWEDISH

9.3 CUSTOM.MATERIAL_TYPE

Modeling requirements

- The value is based on MATERIAL_TYPE and MATERIAL values. A material's generic name. The values are read from the file CustomMaterialType.ini. The values can be on more coarse MATERIAL_TYPE level. Also single MATERIAL values can have a specific value in the .ini file.

Usage

Primarily for IFC export, classifying of structures

Row and value type

ASSEMBLY and CAST_UNIT

Return value (examples):

- String:
 - CONCRETE (BETONI)
 - LECA CONCRETE (KEVYTBETONI)
 - GROUTING (JUOTOSBETONI)
 - AERATED CONCRETE (KAASUBETONI)
 - POLYMER CONCRETE (POLYMEERIBETONI)

 - STEEL (TERÄS)
 - STRUCTURAL STEEL (RAKENNETERÄS)
 - STAINLESS STEEL (RUOSTUMATON TERÄS)
 - ACID PROOF STEEL (HAPONKESTÄVÄ TERÄS)
 - BOLT STEEL (PULTTITERÄS)
 - ROUND STEEL BAR (PYÖRÖTERÄS)

REINFORCING BAR (RAUDOITETERÄS)
 STRAND (JÄNNEPUNOS)
 REINFORCING BAR (HARJATERÄS)
 STAINLESS REINFORCING BAR (RUOSTUMATON HARJATERÄS)

TIMBER (PUU)
 SAWN TIMBER (SAHATAVARA)
 PLYWOOD (VANERI)
 GLUE LAMINATED TIMBER (LIIMAPUU)
 IMPREGNATED TIMBER (KESTOPUU)
 CROSS LAMINATED TIMBER (CLT)
 LAMINATED VENEER LUMBER (KERTOPUU)

MISCELLANEOUS (MUU MATERIAALI)
 EPS INSULATION (EPS-ERISTE)
 XPS INSULATION (XPS-ERISTE)
 PUR INSULATION (PUR-ERISTE)
 ROCK WOOL (MINERAALIVILLA)
 GLASS WOOL (LASIVILLA)
 CELLULOSE WOOL (SELLUVILLA)
 NEOPREN (NEOPREENI)

Supported cast units

- All

It is also possible to append this custom property by .IN_ENGLISH, .IN_FINNISH and .IN_SWEDISH

9.4 CUSTOM.CROSS_SECTION_TYPE

Modeling requirements

- No special requirements. The returned values are based on PROFILE, PROFILE_TYPE and PROFILE.SUBTYPE

Usage

Primarily for IFC export, classifying of structures

Row and value type

ASSEMBLY and CAST_UNIT

Return value:

- String:
 WQ CROSS SECTION (WQ-POIKKILEIKKAUS)
 WELDED BOX (HITSATTU KOTELO)
 WELDED I CROSS SECTION (HITSATTU I-POIKKILEIKKAUS)
 COMPOSITE SHEET (LIITTOLAATAN POIMULEVY)
 I CROSS SECTION (I-POIKKILEIKKAUS)

I CROSS SECTION, SINGLE SLOPE (I-POIKKILEIKKAUS,
 PULPETTIPALKKI)
 I CROSS SECTION, RIDGE BEAM (I-POIKKILEIKKAUS,
 HARJAPALKKI)
 DT CROSS SECTION (TT-POIKKILEIKKAUS)
 DT CROSS SECTION, RIDGE BEAM (TT-POIKKILEIKKAUS,
 HARJAPALKKI)
 LEDGER BEAM, ONE SIDED (LEUKAPALKKI, 1-LEUKAINEN)
 LEDGER BEAM, TWO SIDED (LEUKAPALKKI, 2-LEUKAINEN)
 PLANK SLAB (KUORILAATTA)
 I/H CROSS SECTION (I/H-POIKKILEIKKAUS)
 L CROSS SECTION (L-POIKKILEIKKAUS)
 U/C CROSS SECTION (U/C-POIKKILEIKKAUS)
 T CROSS SECTION (T-POIKKILEIKKAUS)
 RECTANGLE CROSS SECTION (SUORAKAIDEPPOIKKILEIKKAUS)
 ROUND CROSS SECTION (PYÖREÄ POIKKILEIKKAUS)
 RECTANGULAR HOLLOW SECTION (SUORAKEIDEPUTKI)
 CIRCULAR HOLLOW SECTION (PYÖREÄ PUTKI)
 SUPER SLAB, LUJA (SUPERLAATTA)
 SUPER DT SLAB, LUJA (SUPERTT-LAATTA)
 TEK SLAB, PARMA (TEK-LAATTA)
 HAT, BENT (HATTU, TAIVUTETTU)
 L CROSS SECTION, BENT (L-POIKKILEIKKAUS, TAIVUTETTU)
 J CROSS SECTION, BENT (J-POIKKILEIKKAUS, TAIVUTETTU)
 U CROSS SECTION, BENT (U-POIKKILEIKKAUS, TAIVUTETTU)
 V CROSS SECTION, BENT (V-POIKKILEIKKAUS, TAIVUTETTU)
 RIB SLAB, TEK MOULD (RIPALAATTA, TEK-MUOTTI)
 SANDWICH ELEMENT (PVP-ELEMENTTI)
 HOLLOW CORE SLAB (ONTELOLAATTA)
 DELTABEAM (DELTAPALKKI)
 A BEAM, FACTORY CAST (A-PALKKI, TEHDASVALU)
 A BEAM, CAST-IN-PLACE (A-PALKKI, TYÖMAAVALU)
 OTHER CROSS SECTION (MUU POIKKILEIKKAUS)

Supported cast units

- All

It is also possible to append this custom property by .IN_ENGLISH, .IN_FINNISH and .IN_SWEDISH

9.5 CUSTOM.MANUFACTURED_AT

Modeling requirements

- For concrete structures based on CAST_UNIT_TYPE (Precast | Cast in place).
 For other structures based on UDA MANUFACTURED_AT.

Usage

Primarily for IFC export, classifying of structures

Row and value type

ASSEMBLY and CAST_UNIT

Return value:

- String:
 - FACTORY (TEHDAS)
 - CONSTRUCTION SITE (TYÖMAA)

Supported cast units

- All

It is also possible to append this custom property by .IN_ENGLISH, .IN_FINNISH and .IN_SWEDISH

9.6 CUSTOM.IFC_GUID

Modeling requirements

-

Usage

Primarily for IFC export

Row and value type

Return value:

- String: GUID in 22-character format.
 - Tekla Structures uses longer format of GUID
 - Longer and shorter form can be converted into each other.

Supported cast units

- All